

harman/kardon

SOFTWARE UPGRADE INSTRUCTIONS

HK 3700/3770
July 2014

Harman Kardon is pleased to offer this product upgrade, which improves the performance of your stereo receiver.

This Software Upgrade Improves the Following:

- Add Left and Right balance control.

Important Note

This software is specially designed for use with Harman Kardon HK 3700/3770 receivers. Use with any other models or brands may cause damage to the product.

DO NOT USE THIS SOFTWARE WITH ANY OTHER PRODUCTS.

How Can I Tell if My Receiver Needs this Upgrade?

- This software upgrade is the following version: V000.17

Depending on when your stereo receiver was manufactured, it may have already had the latest software installed at the factory.

To see if its software requires an upgrade, please follow these steps:

1. Press the "**FM/AM**" button on the remote to switch ON the stereo receiver.
2. Press the "**Menu**" button on the remote. The front display will show:
Master menu, Network
3. Press the "**down**" navigation button on the remote. The front display show:
Master menu, Software upgrade
4. Press the "**OK**" navigation button on the remote. The front display show:
Upgrade menu, Version: V000.17
5. If the software version shown is "V000.17", your stereo receiver has the latest software version already, and no further action is needed. Press the "**Exit**" button on the remote two times to cancel and exit the menu.
6. If the display shows any other readout, please proceed and carry out the upgrade according to the instructions on page 2.

System requirements:

To install the software upgrade, you will need to UNZIP the software ZIP file onto a USB memory stick with at least 256Mb of available storage capacity. We recommend that to have no other files in the main "root" directory of the memory device. If the root directory does contain any existing files, we recommend that you either remove them or save them to a separate folder on the memory stick.

INSTALLATION INSTRUCTIONS

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE PROCEEDING.

Upgrading your stereo receiver is easy, but for the upgrade to work properly, it is important to carefully follow the instructions below. The upgrade will take less than 3 minutes and once it begins you must complete the entire process in one session.

Please allow sufficient time to complete all the steps.

CAUTION

Installing the new software will erase all information in your stereo receiver system memory, which means that any settings or tuner presets that you have entered will be lost. To make it easier to reestablish the settings after completing the update, we suggest writing down your current system settings and radio presets on a sheet of paper.

Attention: Do not power OFF the stereo receiver or use any of its controls while updating!

1. Insert the USB stick, with the software file, into the USB input on the front panel.
2. Follow the procedure on page 1, point 1 to 5, and press the “**Down**” navigation button on the remote.
3. Front display show:
Upgrade menu, Upgrade start
4. Press the “**OK**” navigation button on the remote
5. SOFTWARE UPDATE begins.
6. During the SOFTWARE UPDATE, the stereo receiver will auto power OFF and ON and show various upgrade text in the front panel display.
7. Finally the stereo receiver will auto power ON and display “UPGRADE SUCCESS”.
8. The stereo receiver switches to FM, but since all memories and presets have been erased, no
9. station is tuned.
10. Power off the unit and remove the USB stick.

Congratulations, your stereo receiver is now upgraded to the latest software version. Before using your stereo receiver, you should re-enter the settings and tuner presets that you wrote down.